



At home out there

Traveller 3

1. Although all frame sections are already numbered, it is recommended that you colour-code them after you have put up the tent for the first time, to make assembling easier in the future. (i.e. using different coloured tape).
2. Place the canvas over the frame, starting at the rear, Ensure that the front and rear are located correctly.
3. Secure the canvas to the frame using the ties at the corners on the inside of the canvas.
4. The ends of the upright poles can be adjusted so that the height of the tent can be made equal to the height of your vehicle.
5. Peg down the entire tent, using the rubber rings and pegs. Make sure all zippers are closed!
6. Assemble the horizontal pole (3 sections and thread it through the sleeve on the flap at the back of the tent.
7. If there is no rim on the roof of your vehicle, you can also attach the tent using a strap or a rope.
8. The loops on the back section can be used to further secure the tent, keeping it closer with your vehicle.
9. Attach the guylines. Tie the guylines to the loops on the outside of the tent and anchor them with pegs.