



ULTRA PORCH AWNING

1. Slide awning onto rail and release flysheet and ensure all zips are closed
2. Assemble poles and lay them parallel on the ground.
3. Slide the 2 largest poles through the flysheet and fit into the corresponding pin and ring on the pole anchor straps.
4. Secure these rings into the ground with pegs provided.
5. Next take the remaining pole and insert into the pocket at the top left of the awning and then clip in horizontally and then fit into the pocket on the opposite side.
6. Peg out the awnings through the rings and straps with the pegs supplied.